



First Time Setup:


1. Connect the USB storage device to the corresponding port on the back of the monitor and power on the monitor.



2. Once the monitor is on, navigate to the menu using the “Home” button - you may see a Magic INFO splash screen autoplaying, the menu should appear at the bottom of the screen.



3. Select “Magic INFO S”.



4. Select connected USB Storage Device.
This should populate the menu screen with compatible media options.



5. Select desired visual media content - it should begin to autoplay.



Returning Setup:

To back out of playing media, press the return button on the remote to return to the Magic INFO S menu.
To change media repeat steps 4. & 5.

Note: As long as the USB storage device has not been removed it should continue to auto-play selected media after powering down the monitor. If this does not occur repeat the above steps.

With slideshows and looping video media it is common for the first playthrough to have rough or non-smooth transitions and a rough or non-smooth loop. After the first playthrough, transitions and loop should be smooth.



The Linenless Table Company

Media Podium Activation

